

Sears Roebuck & Co.

Model: 6321

Chassis:

Year: Pre June 1940

Power:

Circuit:

IF:

Tubes:


Bands:

Resources

Riders Volume 11 - SEARS 11-57

SEARS, ROEBUCK & CO.

MODELS 6321, 6322, 6323, 6421
Ch. 101.571, 101.571-1, -1A, -1B
Schematic, Voltage, Chassis
Socket, Trimmers, Changes



FOR SILVERTONE CHASSIS 101.571

PUSH-BUTTON ADJUSTMENT:
Pull off push button knob to locate slotted screwhead. SETTING UP STATION: Loosen screwhead; tune station; tighten screwhead; thus locking mechanism.

IF PEAK 455 KC

CONVENTIONAL ALIGNMENT SEE SPECIAL SECTION VOLUME VIII

- LOCATIONS OF PARTS ON TOP OF CHASSIS**
- TYPE POWER OUTPUT:**
- YELLOW 1 watt
 - GREEN 1 watt
 - BLACK 1.8 watt
- BEAR TUBE**
- Undersized 1 watt
 - Maximum 1.8 watt