

Emerson Radio & Phonograph Corp.

Model: 77

Chassis:

Year: Pre March 1934

Power:

Circuit:

IF:



Tubes:

Bands:

Resources

Riders Volume 4 - EMERSON 4-4

CIRCUIT DIAGRAM



(Readings in other bulletin are void).

Readings should be made with the Volume Control fully on and the receiver tuned to a position on the dial where no broadcast comes through.

Use only a high resistance d.c. voltmeter.

<u>Ground To:</u>	<u>Plate</u>	<u>Screen</u>	<u>Cathode</u>
56 Oscillator	90-110	_____	_____
58 R.F. Amplifier	235-250	90-110	5-6
58 First Detector	235-250	90-110	5-7
58 I.F. Amplifier	235-250	90-110	5-6
2A6 Audio Amplifier	125-135	_____	1.2-1.4
47 Output Pentode	215-225	235-250	_____

Line Voltage — 115

The bias on the 47 cannot be read with the voltmeter.